

INSTRUCTION LEAFLET FOR:

ROUND AND SQUARE KNOBS, BACK TO BACK MOUNTING.

- PLACE THE PLASTIC TUBE **4** IN PANEL HOLE
- PUT INTO PLACE THE ITEMS **1, 2 & 3** ON THE PANEL INSIDE THE SHOWER.
- PLACE **5** AND **6** ON THE OTHER SIDE OF THE PANEL.
- SCREW **1** ON TO **6** PUTING THE INDENT ON KNOB IN THE RIGHT POSITION.
- PUT **7** INTO POSITION ON **2** ENSURING THAT THE KNOB INDENT IS IN THE RIGHT POSITION.
- TIGHTEN SET SCREW **8** .

